

AGENCY SHOP LTD
INK RIBBON PAPER
COMPANY, UK

TEL: +44 (0) 2085171256;
DOC. REF: 015/7/16



IMPACTING, IMPRESSING AND IMPRINTING MACHINES

IBM/LEXMARK/INFOPRINT

72; **82**; 83, 96; 96C; 102; 196; 201; 202; 270; 301; 302; 360; 719; 739; 1103; 1403 wide line; 1440; 1443 -rapid printer/1/2/Ni; 1445; 1445-1/2/Ni; 1620; 1980; 2201; 2203; 2205

PS/1; 2206; 2300 (PC); 2380; **2380 MOD**; 2381; 2390 PS/1; 2391; **2400**; 2480; 2481;
2490; 2491; 2560 MFKE; 2560 Wire printer; 2580; 2581; 2590; 2591; 2780; 3200; 3203
wide line; 3262; 3282-2; 3289-3; **XYD**; 3614 ATM receipt printer; **3614**

4224, 4226-302, 4227, 4247

535; 550; 5000; 5103 wide line; 5024; 5060; 5120; 5122; 5125; 5133; 5151; 5152 Graphic
(PC); 5153 Graphic Ptr; 5182; 5215; 5222; 5224 baseball bat; 5225; 5227; 5230; 5251
(PC); 5252 wide line (PC); 5256 wide line

6746, 6747 EASYSTRIKE, Wheelwriter 10/1000/1500/2500/3000/3500/5000/7000

711, **713, 715**, 3121 [IBM 1136108]

Imperial

Calculator 400PD, 1300, 1415, 1450, 1460

International

33, 34e, 500, 600, 1000, 1040

Ithaca (TransAct)

Modell 61, Modell 62, Modell 63, Modell 64, Modell 70, Modell 75, Modell 76

MAI

4212, 4214, 4215, 4224, 4225, 4226, 5969,

Mannesman Tally/Genicom

PS220, PS222, 1040, 1040C, GP 1420 PASSBOOK PRINTER,

T2280+, T2340, T2348, T5000, T5023, T5025, T5040, T5200, T6120, T6000, T6045, T6050, T6065, T6101, T6082, T6090, T6091, T6092, T6100, T6140 T6141, T6180, T6212, T6215, T6218, **T6300**, T6306, T6312

Spirit 80, **Spirit Microprinter**

LGe06, LGe12, LGi12, LGi15, LGi18, LGL06, LGL12

LA36, LA36N, LA36W, LA550N, LA550W, LA600, LA650, LA650+, LA800, LA800+

MT35, MT80, MT81, MT82, MT83, MT84, MT85, MT86, MT87, MT88, MT100, MT110, MT130, MT131, MT132 multiform, **MT135**, MT135E, MT139, MT140, MT141, MT150,

MT151, MT180, MT184-99, MT190, MT230, MT230/9, MT230/18, MT230/24, MT240, MT250, MT256, MT280, MT281, MT290, MT300, MT302, MT330, MT330F, MT340, MT340F, MT350, MT360, MT400, MT410, MT420, MT425, MT429, MT440, MT440-L, MT460, MT460D, MT480, MT490, MT490-L MT600, MT614, MT628, **MT645**, MT645CX, MT650, MT651, **MT660**, MT661, MT690, MT691, MT695, MT1000 closed jaw, MT1000 open jaw, MT1200, MT1202, MT1600, MT1602, MT1605, MT1608, MT1700, MT1802, MT2030, MT2060, MT2265, MT2380, MT5025, MT5060, MT6000, **MT6090**, MT 132 MULTIFORM., MT13019, MT130124, MT15019, MT0124

6300 series: 6306, 6312, 636005, 636006 [P/N 086039]

3300, 3400, **3460**, 3470, 3480, 3500, 3560, 3564, 3570, 3580, **3800**, 3810, 3811, 3820, 3830,

Max

Cheque writers: EC30, EC50, EC700]

Nakajima

AE330, AE350, AE800, AE830

AP650, AS300

AX210, AX220, AX200

NCR

2010, 2020, 2106, 2108, 2109, [2109-4](#), [2109-8](#), 2110, [2113](#), [2113-0500](#), [2113-1000](#), [2113-1101](#), [2113-3000](#), [2114](#), 2115, 2116, 2117, 2119, 2120, 2121, 2122, 2126-1300, 2126-1400, 2126-5000, 2126-6000, 2127, 2130, 2135, 2136, 2140, 2147, 2152, 2154, 2160, 2207 receipt, 2209, 2205, 2250, 2251, 2260, 2261, 2270, 2282, 2285, 2552, 2561, 2593, 2760, 2872, 2950, 4125 12EX, 4125 16EX, 5000, 5021, 5067, 5070, 5070 Audit, 5080 ATM, [5084 Piano](#), 5080, 5081, 5085 Piano, 5088, [5223/5223-model 2 passbook](#), 5267, 5411, 5600, [5663](#), [5674](#), 5675, 5682, 5684, 5685, 5688, 5874, 5884, 5886, 6411, 6412, 8512, 6414, 6417, 6417 101, 6417 0201, 6421, 6421 0201, 6424, 6427, [6760/6776/6770/6780](#) Endorser, 7052, 7052 D, 7053, 7053 A, 7053 P, 7050 [receipt journal printer](#), 7150, 7152, [7156](#), [7158](#), [7167](#), [7168](#), [7186](#), [7450](#), [7452](#) cheque endorser.

DM 5, DecisionMate V.

[18-36](#), [18-38](#)

[MA 156](#), [MA 305](#), [MA 315](#)

NEC

PC 8000, PC 8023, PC 8023A, PC 8024, PC 8024A, PC 8025, PC 8026A, PC 8027, PC-PR63A, PC-PR65, PC-PR65LA, PC-PR80LA,.

P1, P2, P2+, P 2Q, P 2X, P3, P 3Q, P5, P6, P 6+, P6+ (4-Colour), P7, P 7+ (Gear), P7+ (4-Colour), P20, P 22Q, P30, P 32Q, P 42Q, P 52Q, P60, P62, P70, P72, P 72X, P90, P760, P765, P1200, **P2200**, P3200, P3300, P5200, P5300, P5300 (4-Colour)

Pinwriter CP2, CP3, CP7, CP6, CP665, CP760, CP765

Pinwriter **P1**, **P2**, P2+, P2Q, **P3**, P3Q, P5, P5XL, P6, **P6+**, **P7+**, **P7**, P9XL, P20, P22Q, P30, P32Q, P33, P60, P70, P72, P90, P530, P530XL, P535, P535XL, P560, P565, P565XL, P660, P760, P960XL, P965XL, P1200,

Spinwriter 2000 series, 3500 series, 5500 series, 5700 series, 7700 series, 8000 series.

Newbury Data

Dre 8000, 8000, 8850, 8925, DP 8510, M1550-S

Okidata

120, 180, 182/390 [B/R], 240, 292, 292 Elite, 293, 293 Elite 390 [Flatbed], **395 wide**, 420, 421, 490, 491, 520, 521, 590, 591, 720, 790, 921, 931, 5320, 5320S, 5520, 5521, 5560, 5590, 5591, 5560, 5650, 5660, 5860, 8223,

Pacemark 2350, 2410, 3410, 4410, 4410N

ET-5200, ET-5300S, ET-5300N, ET-5310, ET-5320, ET-5322, ET-8000 II, ET-8300,

Okimate 10, 20, 120, 240, MCS 810

OkiPOS Series 50, OkiPOS 90, OkiPOS 93, OkiPOS 151, OkiPOS 425D, OkiPOS 425S

Microline [**and ML**]: **80**, 82, 83, 84, 91, 92, 93, 94, 100, 120, 172, 180, **182**, 182 Elite, 182 Turbo, 183, 183 Elite, 184, 184Turbo, 186, 188, 192, 192Elite, 193, 193Elite, 194, 195, 280, 292, 292 Elite, 293, 293 Elite, 294, 320, 320 Elite, 320 Turbo, 320 Flatbed, 321, 321 Elite, 321 Turbo, 325, 351, 380, 385, 386, **390**, 390 Elite, 391, 391 Elite, 393, 393 Elite, 394, 395, 420, 421, 490, 491, 520, 521, 590, 591, 1120, 1190, 2350, 2410,

Olivetti

PR2 Cheque printer, PR-4, PR24, PR24L, PR25, PR25L, PR37, PR38, PR40 Cheque printer, **PR44 Cheque printer**, **PR-45**, PR45SFP, PR-46, PR50 Cheque printer, PR54, PR60, PR320, PR321, PR322 PR1480, **PR2840**

Wordcart, ET221, **ET55**, ET2000, ET2450, ET2500, ETV2700, ETV2800, ETV2900, Lightcart, ET2200, ET2300, ET2300SP

Quickcart, **CWP-1**, CWP-2

Praxis 20, 30, 35, 39, 40, 41, 45, 48; Lexicon 80

DM80, DM99, DM100, DM250, DM250L, DM304, DM309, DM309E, DM324, DM324L, DM409, DM424L, DM509, DM524, DM580, DM590, DM600, DM624, DM624E, DM4100, DM5000, DM5055, DM5100, DM5200

LOGOS 40-43, LOGOS 47-49, 250, **LOGOS 91**, 92, 93eu, 94eu, 440, 442, 444.

Calculator 100, 121 PD, 162 PD, 300, 700PD, EC 700 PD, 701 PD, 710 PD, PD 700, PD 705, PD 706, PD 710, 710 PD, PD 711, 712 PD, PD 710, PD 712, 715 PD, 720 PD, PD 720, PD 800, 800 PD, 900 PD, 910 PD, 920

EC 121, EC 121 PD, EC 122, EC 122 PD, EC 162, EC 162 PD, EC 710 PD, EC 900 PD, EC 910 PD, EC 920 PD,

ECR 001, ECR 002, ECR 003, ECR 007, ECR 011, ECR 012, ERC 25, ECR 100, ECR 100 EV, ECR 200 EV, ECR 300, ECR 300 EV, ECR 400, ECR 400 EV, ECR 2100, ECR 2100 EURO, ECR 2150, ECR 2200, ECR 2200

Olympia

Calculator 2035, 2130, 2135

Compact, Compact I, Compact 12, Compact 13, Electronic Compact, Compact S

Carrera, Carrera 210, Carrera 300 series, Carrera Si, Carrera S, Carrera MD, Carrera de luxe, Carrera Exklusiv, Carrera III BT, Carrera 2000 Electric E560/ES90, ES-70i, ES91, ES300

Splendid, Splendid MD; Standard 300, Supertype 330; Startype 130i/230i, Master type 100i/D

Quickcart CWP-1, **ESW 3000**

CM122, CM12L, CM720, [CM725](#), CM730, CM735, CM880, [CM880CD](#), [CM888](#), [CM888-R](#), CM899, CM1712, CM1736, CM1920, CM1930, CM1935, CM1936, CM2030, CM1688

CPD 12, CPD 12 L, [CPD 123](#), CPD 122, CPD 312, CPD 419, CPD 1010, CPD 2220, CPD 2212, CPD-2512, CPD-3012, CPD-3120, CPD-3210, CPD-3211, CPD-3212, CPD-3212A

PD 150, PD 610, PD 700, PD 700 S, PD 710, [PD 2012](#), PD 3211

[ET8200](#), [S2200](#), [16 PD](#).

Omron

RS-28-10, RS3010, RS-3410, RS-35-10, RS-40-40, RS-40-43, RS-45-41, RS-5500, RS-5510, RS-5540, **RS-5541**, RS-5543, RS-5550, RS-5555, RS-5560, RS-6000, RS-6000-PR60, RS-6000-PR62, RS-7000

POS-50, SP-50, SP-60, SP-85

Panasonic

KX-P series: KX-P1, KX-P15, KX-P100, KX-P110, KX-P110i, KX-P115, KX-P115i, KX-P130, KX-P140, **KX-P145**, KX-P150, KX-P150C, **KX-P155**, KX-P160, KX-P165, KX-P170, KX-P180, KX-P181, KX-P190, KX-P1000, KX-P1030, KX-P1031, **KX-P1080**, KX-P1080AP, KX-P1080i, KX-P1081, KX-P1082, KX-P1090, KX-P1091, KX-P1091i, KX-P1093, KX-P1121, KX-P1123, KX-P1123i, KX-P1124, KX-P1124i, KX-P1125, KX-P1130, KX-1131, KX-P1140, KX-P1150, KX-P1160, KX-P1170, KX-P1180, KX-P1180i, KX-P1190, KX-P1191, KX-P1524, KX-P1540, KX-P1541, KX-P1590, KX-P1592, KX-P1595, **KX-P1624**, KX-P1654, KX-P1695, KX-P2000, KX-P2023, KX-P2021, **KX-P2123**, KX-P2124, KX-P2130, KX-2135, KX-P2150, KX-P2180, KX-P2448, KX-P2450, KX-P2465, KX-P2466, KX-P2480, KX-P2624, KX-P3123, KX-P3124, KX-P3196, **KX-P3200**, KX-P3624, **KX-P3626**, **KX-P3696**, KX-P7100, KX-P9011, KX-P9019, KX-P9100, KX-P9101, KX-P9104, KX-P9606.

KX-R series: KX-R190, KX-R191, KX-R193, KX-R194, KX-R195, KX-R196; KX-W900, KX-W1030

Paymaster

Chequewriter/Signers: 7000, 8000, 8000-10, 8025, 8500-7, 8500-9, 9000-8, 9000-9, 9000-10, 9000-11, 9012-12, 9014, 9015, 9016-11

Philips

P series: P2000 DP, P2000-2123, P2096, P2122, P2123, P2711, P2906, P2908, P2916, P2918, P2980, P294, P402, P2900-990, P2950, P2951, P2962, P2968, P2990, P2999, P3302, P3305, P3306, P3308, P3312, P3313, P3316, P4500, P5700, P7416, P7426, P5381, P5382, P5383, **P6327**, **P6390**, P6371, P6372, P6373

SRC series: SRC17, SRC18, SRC19, SRC39, **SRC46**, **SRC77**, SRC 78, SRC 88, SRC 96, SRC 97, SRC 98

PriceMaster

Hallo 1Y, Hallo 2Y, Hallo 2H

Printek

10SPC, 910, 910HT, 920, 920SPC, 930, 930DD, 930 DLX, 935, **4000**, 4003, 4300

FormsMaster 4003, 4300, 4300 ITX, 4500, 4500 ITX, 4503, 4503 ITX, [8000](#), 8003

FormsPro [200A](#), 2000, 2000 TX, 4000, 4500

Printronix

P150, P180, P215, [P300](#), P300 M, P300 MXQ, P300 XQ, P400, P600, P600M, P600 MVP, P600 MXQ, P700, P900, P3000, P3020, P3040, P3040 CT, P3040 QUIET, P3060, P3240 CT, P3240-NET, P4005, P4008, P4205, P4208, P4212, P4280, P4280-CT, P4280-IPDS, [P5000](#), P5005, P5005A, P5005B-QA, P5008, P5009, P5010, P5015, 5101-QA, P5204, P5205B, P5208, P5209, P5210, P5212, P5214, P5220, P5222s, P5224

PSI

PP 404, PP405, PP407, PP408, PP803, PP804, PP805, PP806, PP809

Quen Data

DMP 1800G, DMP 1836LQ, DMP 1836Q, DWP 1120, DWP 1120VC

Radio Shack [Tandy]

420, DMP 300, DMP 400, DMP 420, LP-VII, LP-VI

Remington

Quiet Rite, etc

Remstar

3000, 5000

Rototype

CBD 1000/H, CBX 6000, CSD 2002, CSD 2000EC, CDM 2000 cheque deposit machine

[SM 6](#), [SM 6B](#), [SM 613](#), [CCS 100](#), [ERS 3000](#), [ERS 5000 data processor](#)

Royal/Royal Adler/Triumph Adler

Calculator Models [12X](#), [12XRD](#), [26PD](#), [40PD](#), [45PD](#), [50P](#), 55PD, 90PD, 100PD, 100P, 100XP, 100NX, 101CX, 101CXRF, 101PD, 101XP, 101xpc, [101XPD](#), 107, 107PD, 110P,

110CXRF, 1950PD, 011PD NOVA, 1012PD, 1012PD II, 1121PD, 1123PD NOVA, 1124PD, 1200, [1201PD](#), 1204, 1205, 1206P, 1210, 1212P, 1218, 1240, 1415, 1425, 1425PD, 1620, [2240](#), 7800HD, [8112PD](#), [8150NT](#), [8150NX](#), [8160NT](#), [8160NX](#), [8210PD](#), [8212PD](#),

Calculator Models EZvue 8500 PD, [EZvue 550 HD](#), EZvue 6500 HD, EZ vue 6800HD, EZvue 7800HD, 8MD 10

Calculator Models [PD1](#), [PD2](#), PD3, PD4, PD5, PD9, PD10

Gabrielle 9009, SE310, BSM100, 8008

ER125, ER135, ER140, ER145, [ER185 ink roller](#), ER205, ER244, ER470, ER246, ER1165, ER1402, ER1412, ER1710, ER1710A,

[CMS-118+](#), CMS-120, [CMS-120+](#), CMS-125, CMS-125+, CMS-128, CMS-200, CMS-214, CMS-215, [CMS-215+](#), CMS-225, CMS-487, [CMS-8121](#), [CMS-8150+](#), [CMS-1850NX](#), [CMS-8150NT](#), [CMS-8160](#), [CMS-8160+](#),

MA-135

Samsung

SP 0912, SP 0915, SP 903, SP 0930N, SP 2320, SP 2411, [SP 2412](#), [SP 2417](#), SP 2420,

SP 2421, SP 2422

SF4300, SF4500, SF4500C, SF4700, SF430,

SQ1000, SQ1200, SQ2200, SQ3200

ER350, ER550, ER 655, ER100, ER101, ER120, ER150, ER200, ER210, ER220, ER240,
ER250, ER290, ER1710, ER1710A, ER1805, ER1810, ER1826, ER2610, ER2615,
ER2700, ER2710, ER2715, ER3615, ER3700,

Sanyo

ECR100, ECR100-2, ECR105, ECR110-2, ECR115, ECR120, ECR138, ECR140,
ECR150, ECR160, ECR165, ECR170, ECR175, ECR225, ECR235, ECR238, ECR270,
ECR280, ECR290, ECR290-4, ECR298, ECR300, ECR305, ECR322, ECR325, ECR335,
ECR 338, ECR355, ECR 360, ECR 365, ECR 375, ECR 380, ECR400, ECR 450, ECR
460, ECR 470, ECR480, ECR 500, ECR 505, ECR510, ECR 515, ECR 520, ECR540,
ECR550, ECR560, ECR570, ECR600, ECR650, ECR3300, ECR3380, ECR 4400, ECR
4810, ECR 4818, ECR5400, ECR5800, ECR6020.

Seiko/Seikosha

SBP-10, SBP-10 AI, SBP -10 CX, SBP-10 L, SBP-10 PLUS, SBP-10 TX, SBP-105I

ST-10

SP800, SP2000, SP2400

Sharp

Calculator [1192](#), [1192C](#), [1192G](#), [1192D](#), [1192 H](#), [1192 S](#), 1197, 1199, 1611, 1620 S, 1706, 1801, 2054, 2062, 2063, 2137, 2156, 2158, 2159, 2166, 2168, 2169, 2173, 2181, 2185, 2189, 2606, 2608, 2617, 2620 S, 5005

[EL-1625H](#), EL-1801, EL-1801A, EL-1801All, EL-1801C, EL-1701C, EL-1750,

EA-718R, EA-720R, EA-732R, EA-740R, EA-741R, EA-770R, EA-772R, EA-780, EA-781, EA-910A,

[ER-2370](#), [ER-2371](#), [ER-2380](#), [ER-2381](#), [ER-2385](#), [ER-2386](#), [ER-2390](#), [ER2391](#), [ER-2395](#), [ER-A330](#), ER-A470;

PA 3000, PA3100, PA3101

ZX 400, ZX 510

QL100, QL110, QL300, etc

Star Micronics

LC 10, LC 10 II, LC 15, LC 20, LC 90, LC 100, LC 100+, **LC 200 (BK)**, LC 1000, LC 1521, LC 2021, LC 24-10 (BK), LC 24-20, LC 24-40, LC 24-100, LC 24-200, LC 4511, LC 4521, LC 4541, LC 7211

MP212, MP216, MP300, MP312, MP312f-24, MP322 S, MP323 S, MP334 N, MP334 S

N10, N24-10, NB24-10, NB24-15, NB10, NB15, ND10, ND15, NP10

NX10, NX2430, NX2450, NX2480

SP-100, **SP-200**, SP-212, SP-298, **SP-300**, SP-302, SP-311, SP-316, SP-320, SP-321, SP-322, SP-323, SP-341, SP-342, SP-349, SP-350, SP-400, SP-500, SP-600, **SP-700**, SP-2000, SP-2320, SP-2360, SP-2520

Swintec

Calculator 300DP, 301DP, 401DP, 401DPS, 4500DP

TEC

MA08, MA55, MA58, MA59, MA68, MA70, MA71, MA78, MA79, MA80, MA85, MA100,

MA115R, MA115-104, MA115-200, MA115-208, MA120, MA128, MA130, MA132, MA133, MA134, [MA135](#), MA136, [MA140](#), MA141, [MA150](#), M156, [MA160](#), MA170, MA180, MA190, MA191, MA200, MA205, MA206, MA215, MA216, MA218, MA225, MA227, MA229, [MA230](#), MA230 new, MA270, [MA290](#), MA290 new, MA300, MA305, MA305-R, MA315, MA400, MA450, MA500, MA516, MA700, MA800, MA1000, MA1040, MA1050, MA1060, MA1070, MA1100, MA1190, MA1300, MA1350, MA1400, MA1450, MA1600, MA1650, MA1700, MA1900, MA2100, [MA2200](#), MA2200 (no eyelets), [MA2300](#), [MA2400](#), [M2600](#), MA4500, MA5500

Texas Instruments [TI]

300, 600, 711, 771, 800, 810, 815, 817, 820, 830, 830e, 825, 850, [860](#), [865](#), 880, 885, 895E, 3400, 3421, 3431, 3432, 5000, 8920, 8930

Omni 820, Omni 830, Omni 830e, Omni 835, Omni 835e, Omni 800 model 820, Omni 800 model 830, Omni 800 model 830e, Omni 800 model 835, Omni 800 model 835e, Omni 800 model 875 color, Omni 800 model 8.

[TI-99-4](#), [TI-99-4A](#), [TI-300](#), TI-320V, TI-635, [TI-711](#), [TI-771](#), [TI-800](#), TI-802, TI-810 PD, TI-817, TI-820, TI-825, TI-830, TI-830E, TI-850, TI-860, TI-865, TI-880, TI-885, TI--895E, TI-1880, TI-3400, TI-3421, TI-3431, TI-5000, TI-5005, TI5005 II, TI-5005 IIB, TI-5006, TI-5006 II, TI-5015, TI-5019, TI-5019 SV, TI-5024, TI-5027

Toshiba

P321, P321SL, P321 SLC, P341, P341E, P341SL, **P351**, P1340, P1350, P1010, P1150, P1240, P1340, P1350, P1351

MA-156, MA-186, MA-516, MA-1595, MA-1655.

Transaction Printer Group (TPG)

756, 758, 7156, 7158, B-780

Triumph Adler

10 HPD, 10 XP, 10 XPD, 12X, 12 XP, 12 XPD, 30 HPD, 40 P, 40 PD, 45 P, 45 PD, 50 P, 50P, 50 PD, 55 P, 55PD107 PD, 121 XP, 121 XPD, 315 PD, 912 PD, 100 P, 100 PD, 101 PD, 101 XP, 101 XPC, 101 XPD, 110 P, 110 PD, 210 PD, 300 P, 300 PD, 410 P, 410 PD, 450 PD, 1010 P, 1010 PD

Micro 101 PD, Micro 121 PD, Micro 212 PD

Universal Calculator

C-Wind, S-Wind spools

Verifone

Ruby System M930

P100, P150, P220, P250, P250-POS, P330, P500, P900

[Tranz 330](#), [Tranz 380](#), [Tranz 420](#), [Tranz 460](#) .

Omni 460, Omni 3200, Omni 3200se, Omni 3750.

Victor

Calculator 100, 120, 350, 600, 605, 610, 620, 660, 820, 830, 840, 860, 870, 1205, 1208, 1208-2, 1210, 1210-2, 1212, 1212-2, 1228, 1220, 1220-2, 1220-3, 1220-4, 1225-2, 1228, 1228-2, 1230, 1230-2, 1230-3, 1242, 1250, 1245, PD 1245, 1255, 1280iii, 1297, 1430, 1530, 1500, 1550, 1555, 1570-5, 1600, 1670, 1675, 2000, 2010, 2700, 3008, 3015, 3100, 3600, 3700, 4000, 4500, 4600, 4700, 4800, 4900, 5000, 6010, 6020, 6025, 6035, 6040..

Widmer

S-3, S-3C, SX-3

R-3, R-3-S, RS-S, RS-O, RS-B, RS-D, RS-DT, RS-MN

WTV-175, WTV T-4U, T-4U

776, 776e, TV-776

Xerox/Diablo

600 series, 6015 series, Diablo Tytype II